

Birch Drawerbox with Undermount Soft Close Slides Installation Instructions

Each birch drawer box comes with:

- Two undermount drawer slides with soft close
- Pre-assembled drawer box with drawer front in your selected color and style
- Adjustable drawer “clip” hardware with release lever (pre-installed on underside of drawer box)
- Screws to secure slides to cabinet



Drawers should be one of the last things you installed on your new Closet Works system. Make sure you have assembled the panels and shelves prior to attaching the door slides to the system. Shelves cannot be added under the bottom of a drawer after the drawers and slides are in place.

Easy Step-By-Step Installation

Be certain the system is plumb and level before installing drawers.

STEP 1

Locate the **third hole** (second down and third over) in the front of the metal slide. Resting the slide against the shelf, align this hole with the pre-bored hole in the side panel. The rear hole will automatically align with another pre-bored hole in back. (Runners that are resting directly on shelves, may require the screws to be inserted on a slight angle down).



STEP 2

Secure the first drawer slide to the system panel using the supplied screws. Starting with the right slide, front holes, align the **third hole** of the slide to panel's pre-drilled hole and secure it with the Euroscrew screw 5mm x 7/16" (item 1149).



STEP 3

Proceed to secure the rear hole of the slide with another Euroscrew 5mm x 7/16" screw. The holes will automatically align with one of the pre-bored panel system holes if step 2 was correctly completed.



STEP 4

Repeat steps 1-3 to install the opposite drawer slide.



STEP 5

Install the drawers by pulling out the installed slides and placing the drawer box over the extended slides. Pull the extended slides into the drawer until they click into place.



STEP 6

All drawers are adjustable up and down by moving the adjustment knob in the corner of the drawer clips (see picture). Use this knob to fine tune the space between the drawer fronts.



STEP 7

To Remove Drawer Box: Open drawer, reach under drawer and depress the "Release Lever" in the front right and left side of the underside of the drawer box. Then drawer can be lifted out of the system.

